


IPC-842C Quick Start Guide



Setup Instructions

1. Power on each IPC-842C with the provided 12VDC power supply.
2. Connect each end of the coax cable to the G.hn port of the IPC-842C's.
3. Check the G.hn connectivity status LEDs on the front of the device to ensure the Ethernet over Coax link has been established.

